

IMS LABORATORY

Lift Tape Mold Test Kit

Directions for Use

1. Label the tape with your sample location.
2. Remove the tape from its backing.
3. Position the adhesive side of the tape over the suspect area and press lightly. (Do not rub back and forth).

There should be a light deposit of material in square window on the tape.



4. Replace the tape onto the liner to its original position.
5. Complete the “Information Form” and place the tape(s) and the information form in the postage paid return envelope provided with your kit.
6. Mail the test kit together with payment back to IMS Laboratory.

IMS LABORATORY
3250 Old Farm Lane, Suite 1
Walled Lake, MI 48390
(877) 665-3373

Visit us on the Web:
www.homemoldtestkit.com